



**Swim Force**

A Comprehensive Swimmer Tracking System

Cole Griscavage & Omar Ebied  
Professor Zucker

# Introduction

- We proposed a comprehensive swimmer tracking system designed to improve performance analysis in swimming.
- Through the use of Ultrasonic transducers and underwater cameras, the system aims to provide precise data on swimmer velocity and enhance training feedback through automated footage sorting.
- By addressing inefficiencies in current training methods, SwimForce facilitates timely and personalized coaching for athletes.

01

# Goals & Overview



Build ultrasonic transducer to emit customizable frequencies



Waterproof the device & test with hydrophone in pool environment



Use PoE cameras to capture clear footage look up from the bottom of the pool



Write program to use hydrophone data to detect when a swimmer comes in range




Edit program to sync camera input with hydrophone input to capture clips



Use OpenCV to calculate swimmer velocity in acquired clips



Edit program to collect and sort clips & data by athlete name





Build ultrasonic transducer to emit customizable frequencies



Waterproof the device & test with hydrophone in pool environment



Use PoE cameras to capture clear footage look up from the bottom of the pool



Write program to use hydrophone data to detect when a swimmer comes in range



Edit program to sync camera input with hydrophone input to capture clips




Use OpenCV to calculate swimmer velocity in acquired clips



Edit program to collect and sort clips & data by athlete name

# Timeline



02

# Technical Aspects



# Programming Techniques

Python program to import the Analog Discovery 2 waveforms framework and collect audio through the hydrophone

```
import numpy as np
import time
import ctypes
import matplotlib.pyplot as plt
from scipy.signal import butter, lfilter

# === Load WaveForms SDK ===
dwf = ctypes.CDLL("/Library/Frameworks/dwf.framework/dwf")

# === Parameters ===
SAMPLE_RATE = 250_000 # 200 kHz
BUFFER_SIZE = 16384 # Match WaveForms settings
PULSE_DURATION = 10 # Monitor for 10 seconds
ORDER = 4 # Order of the bandpass filter
LOG_INTERVAL = 0.01 # Log data every 0.01 seconds
THRESHOLD_DBV = -70 # Threshold for logging timestamps

# Frequency ranges per person
PEOPLE = {
    # "cami": (19000, 21000),
    # "omar": (20100, 20300),
    "cole": (99000, 101000),
    # "ham": (49000, 51000),
}

# Track threshold crossings
swim_ins = {name: 0 for name in PEOPLE}
last_crossed = {name: False for name in PEOPLE}

# === Store data ===
timestamp_dbv_data = {name: [] for name in PEOPLE}
thresh_crossings = {name: [] for name in PEOPLE}

... # Device Initialization ...
```

```

# === Main Loop ===
hdf = open_device()
if hdf:
    configure_device(hdf)
    start_time = time.time()
    last_log_time = start_time
    collecting = True

while time.time() - start_time < PULSE_DURATION:
    current_time = time.time()

    if collecting and current_time - last_log_time >= LOG_INTERVAL:
        last_log_time = current_time
        collecting = False
    elif not collecting and current_time - last_log_time >= LOG_INTERVAL:
        last_log_time = current_time
        collecting = True

    if collecting:
        data = read_data(hdf)

        for name, (low, high) in PEOPLE.items():
            filtered_data = butter_bandpass_filter(data, low, high, SAMPLE_RATE, order=ORDER)

            # Apply windowing and FFT
            window = np.blackman(len(filtered_data))
            windowed = filtered_data * window
            correction_factor = np.sum(window) / len(filtered_data)
            fft_result = np.fft.rfft(windowed) / (BUFFER_SIZE * correction_factor)
            magnitudes = 20 * np.log10(np.abs(fft_result) + 1e-12)

            freqs = np.fft.rfftfreq(len(filtered_data), 1 / SAMPLE_RATE)
            target_idx = np.where((freqs >= low) & (freqs <= high))[0]

            if len(target_idx) > 0:
                peak_dbv = np.max(magnitudes[target_idx])
                timestamp = current_time - start_time
                timestamp_dbv_data[name].append((timestamp, peak_dbv))

            if peak_dbv > THRESHOLD_DBV:
                # Check for new threshold crossing
                if not last_crossed[name]:
                    swim_ins[name] += 1
                    last_crossed[name] = True
                    print(f"{name} swam in at {timestamp:.2f} sec")
                    thresh_crossings[name].append(timestamp)
                else:
                    last_crossed[name] = False

close_device(hdf)

```



Main loop containing FFT calculations to create spectrum from audio data



Initialized, configured, and read data from Analog Discovery 2 prior to main loop



Defined bandpass filter to hone in on specified frequencies



Main loop collects data in intervals to reduce irrelevant data being read



Use windowing before performing the FFT to improve accuracy of frequency analysis.








Could get the dwf FFT analysis to work properly, had to resort to numpy




Check for threshold crossing to detect if a swimmer came in range


# The Beeper








```
1  const int pin = 6;
2  const int time_on = 500;
3  const int time_off = 500;
4
5  void setup() {
6      // put your setup code here, to run once:
7
8  }
9
10 void loop() {
11     // put your main code here, to run repeatedly:
12     tone(pin, 40000); // Play tone at 9500 Hz
13     delay(time_on);   // Wait for the duration specified in 'time'
14     noTone(pin);      // Stop the tone
15     delay(time_off);  // Wait for the same duration before repeating
16 }
```











# Video Footage / Object Tracking



## Dual camera footage



## Next Steps



Build ultrasonic transducer to emit customizable frequencies



Waterproof the device & test with hydrophone in pool environment



Use PoE cameras to capture clear footage look up from the bottom of the pool



Write program to use hydrophone data to detect when a swimmer comes in range



**Edit program to sync camera input with hydrophone input to capture clips**



**Use OpenCV to calculate swimmer velocity in acquired clips**



**Edit program to collect and sort clips & data by athlete name**

# Thank You!

